

44L black 25 function compact combination microwave oven with 90 assisted cooking programs, CookSmart TFT touchscreen and included food probe



Product Details

FEATURES

Convection, microwave, grill
and combination cooking
mode

1000W power

Food probe
Smart food probe monitors
the core temperature of food
to keep meat succulent and
juicy.

90 assisted cooking programs

Triple glazed oven door

Soft close door

BENEFITS

DELICIOUS DISHES. FASTER.

CombiQuick cooks food much faster than standard ovens, without compromising on flavour. By combining convection oven functions with the grill and microwave, you can serve delicious meals no matter how much time you have.

COOKING GUIDANCE AT A TOUCH

The CookSmart Touch display effortlessly guides you to perfect cooking results. Cook more efficiently, save your favourite recipes in the app, and send them straight to the oven for simple, smart cooking.

PRECISE COOKING, GREAT RESULTS

The smart food probe monitors the core temperature of your food, while precise sensors alert you when the dish is ready, and stop the oven automatically so the roast stays juicy, just the way you like it.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	3
Type of Oven	compact oven
Oven fuel	electric
Materials/Colour	black
Controls of Oven	CookSmart Touch TFT
Cooling fan	Yes

MAIN OVEN

Gross capacity litres	49
Useable capacity litres	44
Oven function	multifunction
Number of functions	25

DIMENSIONS

PRODUCT DIMENSION

Total height (mm)	456
Total width (mm)	595
Total depth (mm)	571

ELECTRICAL CONNECTION

Connected load KW	3
Maximum current rating (amps)	16
Type of connection	hardwired

MAIN OVEN

Oven Functions	roast,grill,keep warm,defrost,top heat,bottom heat,slow cook,microwave and true fan,microwave and grill,microwave,top+bottom,bread baking,dough proving,plate warming,preserving,microwave and turbo grill ,Dehydrating,microwave and conventional cooking,Hot air,Hot air + top,Hot air + bottom,Hot air, top + bottom,Reheat,Stew,Melt
Oven liner	enamel
Timer functions	acoustic signal,duration,minute minder,Auto off ,End time,Delayed start,Time of day,Time extension,Uptimer
Light wattage	25

OTHER FEATURES

Number of Programmed functions	90
Auto cook programs	Yes
Door	drop down,Soft close
Timer	Fully programmable touch control timer
Lights	1

SHIPPING

Shipping Volume (m3)	0.236
Shipping Weight (Kg)	35
Pack Dimensions Height (mm)	555
Pack Dimension Width (mm)	635
Pack Dimension Depth (mm)	670

OTHER FEATURES

Light wattage	25
Light position	top
Shelf support	side rack
Safety features	child button lock, Triple glazed door
Closed door grilling	Yes
Included accessories	Smart food probe, dripping pan, cake tray, Chromed wire shelf
Layers of glass in door	3
Number of shelf positions	3
Food probe	Yes

Model:
EVEN6847ZB

Technical drawing of the H05 V V - F cabinet, showing front, side, and top views with dimensions and assembly details.

Front View Dimensions:

- Top width: 558⁺¹
- Top depth: 550
- Top right corner: 21
- Right side height: 114
- Right side depth: 456
- Right side bottom depth: 451
- Bottom depth: 595⁺¹
- Bottom width: 306
- Left side height: 438
- Top left corner: 18

Side View Dimensions:

- Top width: 558⁺¹
- Top depth: 550
- Top right corner: 21
- Right side height: 114
- Right side depth: 456
- Right side bottom depth: 451
- Bottom depth: 595⁺¹
- Bottom width: 306
- Left side height: 438
- Top left corner: 18

Top View Dimensions:

- Top width: 558⁺¹
- Top depth: 550
- Top right corner: 21
- Right side height: 114
- Right side depth: 456
- Right side bottom depth: 451
- Bottom depth: 595⁺¹
- Bottom width: 306
- Left side height: 438
- Top left corner: 18

Assembly Details:

- Top View:** Shows the top panel with dimensions 90, 30, 360, 30, 50, 215, and 120. It also shows the top panel being attached to the side panel with a screw.
- Side View:** Shows the side panel with dimensions 90, 30, 360, 30, 50, 215, and 120. It also shows the side panel being attached to the top panel with a screw.
- Front View:** Shows the front panel with dimensions 90, 30, 360, 30, 50, 215, and 120. It also shows the front panel being attached to the side panel with a screw.
- Bottom View:** Shows the bottom panel with dimensions 90, 30, 360, 30, 50, 215, and 120. It also shows the bottom panel being attached to the side panel with a screw.
- Warning:** A warning symbol (exclamation mark inside a triangle) is shown next to the bottom panel, indicating a warning.
- Assembly Instructions:** Two circular diagrams show the assembly of the top panel. The first diagram shows a screw (3,5x25) being inserted into the top panel. The second diagram shows the top panel being attached to the side panel.
- Bottom Panel:** A circular diagram shows the bottom panel being attached to the side panel with a screw (3,5x25).
- Bottom Panel Dimensions:** The bottom panel has a width of 145 and a height of 360.
- Bottom Panel Label:** The bottom panel is labeled "H05 V V - F".

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz